



Hemel Engineering Products, Inc.
6520 Lockport Road • Niagara Falls, New York 14305-3597
Telephone (716) 297-8644 • Fax (716) 297-9405
Email sales@hemel.com • Web www.hemel.com



Many Geomet® customers have expressed interest in opening GEOMET files off-line at any PC. Hemel announces our new “**GeoViewer**” software product to make this happen.

GeoViewer installs on any Windows XP or Vista PC except the PC that runs your Geomet software on the CMM. Here is what you can do:

- Open any Geomet inspection file produced on Version 6.66.002 or later.
- GeoViewer automatically detects and uses the source file version.
- For sub-Geomet 101 versions (Geomet Junior) it defaults to 101 mode and shows graphics.
- Stylus databases are ignored.
- View inspection files with interactive graphics and print Geomet reports.
- FILE menu functions are fully active.
- Other available functions →
 - Edit or Apply Tolerance
 - Add new GeoTol Form Tolerance steps
 - Cone Offset
 - Cone Diameter
 - Cone Ball Drop
 - Sphere Offset
 - Sphere Diameter
 - Full suite of Graphic Tools
 - IGES Export
 - DXF Data Point Export
 - Edit Header
 - Concise and Report Ordering in appropriate levels
 - Move and Delete features
 - Right-click option only supports basic state changes
 - Circle Profile including printing
 - Feature Profile (Planar) including printing

Restricted features include other Construction types, Recalls, Inserting features, Tagging, and SPC Export.
