## **UCCT5 CONTROLLER**

CMM controller for 5-axis touch-trigger motion and head control - PH20 only



- · Must be used in conjunction with a Renishaw SPA3 amplifier
- Uses an external power supply and manages full control of the PH20 head, CMM and probe signals and communicates with the CMM's computer
- Has optional integral thermal error compensation (TEC) with support for 16 channels of temperature compensation
- Setup and commissioning completed through Renishaw's UCCassist-2 software
- Probe System management via UCC Server software



